



PARTS MANUAL FOR GAS BRAISING PANS G30 TB & G40 TB




Model G30 TB



BRAISING PAN ASSEMBLY

BRAISING PAN ASSEMBLY


ILLUS. PL-51485	PART NO.	NAME OF PART	AMT.
1	844367-65	Thermocouple	
2	844367-64	Thermostat - Hi-Limit	
3	844367-16	Shaft	
4	844367-58	Motor 120 V.	
5	844367-1	Top - Cover (G30TB)	
6	844367-2	Top - Cover (G40TB)	
7	836958	Foot - Flanged Adjustable (Rear)	
8	840590	Insert - Adjustable Foot (Front)	
9	844367-28	Strainer	



CONTROL PANEL & GAS PIPING

CONTROL PANEL & GAS PIPING


ILLUS. PL-51487	PART NO.	NAME OF PART	AMT.
1	844367-59	Valve - Gas Shut-Off	
2	844367-47	Regulator - Gas Pressure (Nat)	
3	844367-48	Regulator - Gas Pressure (LP)	
4	844367-49	Solenoid - Gas	
5	844367-50	Ignition Module	
6	844367-13	Switch - Limit	
7	844367-60	Ignition Wire Harness	
8	844367-53	Controler - Temperature	
9	844367-56	Transformer	
10	844367-57	Capacitor	
11	844367-3	Switch (Up/Down)	
12	844367-5	Bezel	
13	844367-6	Dial	
14	844367-55	Light - Pilot (Red)	
15	844367-54	Light - Pilot (Green)	
16	844367-8	Lug - Ground	
17	844367-81	Panel - Control (G30TB)	
18	844367-82	Panel - Control (G40TB)	
19	844367-77	Overlay (G30TB)	
20	844367-78	Overlay (G40TB)	
21	844367-51	Block - Terminal	
22	844367-52	Section - End	



BURNER

BURNER

ILLUS. PL-51495	PART NO.	NAME OF PART	AMT.
1	844367-62	Coil - Glow	
2	844367-63	Burner	
3	844367-73	Orifice - Burner (Nat)(G30TB)	
4	844367-74	Orifice - Burner (LP)(G30TB)	
5	844367-75	Orifice - Burner (Nat)(G40TB)	
6	844367-76	Orifice - Burner (LP)(G40TB)	
7	844367-69	Nipple - Orifice	
8	844367-61	Sub - Manifold	
9	844367-66	Sensor - Flame	
10	844367-70	Orifice - Lighter #56 (Nat)	
11	844367-71	Orifice - Lighter # 65 (LP)(G30TB)	
12	844367-72	Orifice - Lighter # 72 (LP)(G40TB)	
13	844367-67	Tube - Lighter (G30TB)	
14	844367-68	Tube - Lighter (G40TB)	



HINGE ASSEMBLY

ILLUS. PL-51489	PART NO.	NAME OF PART	AMT.
1	844367-38	End - Stop Plate (30TB)	
2	844367-46	End - Stop Plate (40TB)	
3	844367-37	Disc - Rotary (30TB)	
4	844367-45	Disc - Rotary (40TB)	
5	844367-35	Spring (30TB)	
6	844367-43	Spring (40TB)	
7	844367-34	Core (30TB)	
8	844367-42	Core (40TB)	
9	844367-33	Disc - Stationary (30TB)	
10	844367-41	Disc - Stationary (40TB)	
11	844367-32	End - Lock Plate (30TB)	
12	844367-40	End - Lock Plate (40TB)	
13	844367-31	Lockpin (30TB)	
14	844367-39	Lockpin (40TB)	
15	844367-36	Cap Screw (30TB)	
16	844367-44	Cap Screw (40TB)	